

# Inspiron 11 3000

## Setup and Specifications

Computer Model: Inspiron 11-3179  
Regulatory Model: P25T  
Regulatory Type: P25T002



# Notes, cautions, and warnings

---



**NOTE:** A NOTE indicates important information that helps you make better use of your computer.



**CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



**WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

---

© 2016 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2016-07

Rev. A00

# Contents

<b>Set up your computer.....</b>	<b>5</b>
<b>Views.....</b>	<b>8</b>
Left.....	8
Right.....	8
Base.....	9
Display.....	10
Modes.....	11
Notebook.....	11
Tablet.....	11
Stand.....	12
Tent.....	12
<b>Specifications.....</b>	<b>13</b>
Dimensions and weight.....	13
System Information.....	13
Memory.....	13
Ports and Connectors.....	14
Communications.....	14
Video.....	14
Audio.....	14
Storage.....	15
Media-card reader.....	15
Display.....	15
Keyboard.....	16
Camera.....	16
Touch pad.....	16
Battery.....	17
Power Adapter.....	17
Computer Environment.....	18

<b>Keyboard shortcuts.....</b>	<b>19</b>
<b>Getting help and contacting Dell.....</b>	<b>20</b>
Self-help resources.....	20
Contacting Dell.....	21

# Set up your computer


---

- 1 Connect the power adapter and press the power button.




2 When your computer is switched on for the first time, you will be prompted to complete these steps:


a) Enable security and Dell updates.



b) Connect to a wireless network.



c) Sign-in to your Microsoft account or create a new account.



**3** Explore Dell resources on your desktop.



Help and Tips



My Dell




Register your computer

# Views

---

## Left



1 **Power-adaptor port**

Connect a power adapter to provide power to your computer and charge the battery.

2 **HDMI port**

Connect a TV or another HDMI-in enabled device. Provides video and audio output.


3 **USB 3.0 port**

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

4 **microSD-card slot**

Reads from and writes to media cards.

## Right



1 **Power button**

Press to turn on the computer if it is turned off or in Sleep state.

Press to put the computer in Sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.





**NOTE:** You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at [www.dell.com/support/manuals](http://www.dell.com/support/manuals).

**2 Volume-control button**

Press to increase or decrease the volume.

**3 Headset port**

Connect a headphone, a microphone, or a headset (headphone and microphone combo).


**4 USB 2.0 ports (2)**

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

**5 Security-cable slot**

Connect a Noble security-cable to prevent unauthorized movement of your computer.

## Base



**1 Left-click area**

Press to left-click.


**2 Touch pad**

Move your finger on the touch pad to move the mouse pointer. Tap to left-click.

### 3 **Right-click area**

Press to right-click.

## Display



### 1 **Left microphone**

Provides high-quality digital sound input for audio recording, voice calls, and so on.

### 2 **Camera**

Allows you to video chat, capture photos, and record videos.

### 3 **Camera-status light**

Turns on when the camera is in use.

### 4 **Right microphone**

Provides high-quality digital sound input for audio recording, voice calls, and so on.

# Modes

## Notebook



## Tablet



**Stand**



**Tent**



# Specifications

---

## Dimensions and weight

Height	21.85 mm (0.86 in)
Width	291.61 mm (11.48 in)
Depth	201.92 mm (7.95 in)
Weight	1.35 kg (2.98 lb)



**NOTE:** The weight of your laptop varies depending on the configuration ordered and the manufacturing variability.

## System Information

---

### Inspiron 11–3179

---

Processor	<ul style="list-style-type: none"><li>• 7th generation Intel Core i5</li><li>• 7th generation Intel Core i7</li><li>• 7th generation Intel Core m3</li></ul>
Chipset	Integrated in processor

## Memory

Slot	Integrated in processor
Type	DDR3L
Speed	1600 MHz
Configurations supported	4 GB

# Ports and Connectors

---

## External:

---

USB

- One USB 3.0 port
- Two USB 2.0 ports

Audio/Video

- One HDMI port
- One headset (headphone and microphone combo) port

---

## Internal:

---

M.2

One M.2 slot for Wi-Fi and Bluetooth combo card

# Communications

Wireless

- Wi-Fi 802.11 b/g/n/ac
- Wi-Fi 802.11 ac
- Bluetooth 4.0
- Miracast

# Video

Controller

Intel HD Graphics 615

Memory

Shared system memory

# Audio

Controller

Realtek ALC3246 with Waves MaxxAudio

Speakers

Two

Output

- Average 2 W

Microphone

- Peak 2.5 W

Digital array-microphones in camera assembly

Volume controls

Media-control shortcut keys and volume-control buttons

## Storage

Interface

SATA 6 Gbps

Hard drive

- One 2.5-inch drive
- One Solid State Drive (SSD)

## Media-card reader

Type

One microSD-card slot

Card supported

microSD

## Display

Type

11.6-inch HD touch

Resolution (maximum)

1366 x 768

Pixel pitch

0.2265 mm

Refresh rate

60 Hz

Operating angle

0 degrees (closed) to 360 degrees

Controls

Brightness can be controlled using shortcut keys

Height

144 mm (5.67 in)

Width

256.13 mm (10.08 in)

Diagonal

294.64 mm (11.60 in)

# Keyboard

Type

Chiclet keyboard

Shortcut keys

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.



**NOTE:** You can define the primary behavior of the shortcut keys by pressing Fn+Esc or by changing Function Key Behavior in System Setup.

[Keyboard shortcuts](#)

# Camera

Resolution

- Still image: 0.92 megapixel
- Video: 1280 x 720 (HD) at 30 fps (maximum)

Diagonal viewing angle

74 degrees

# Touch pad

Resolution

- Horizontal: 1940
- Vertical: 1040

Dimensions

- Width: 100 mm (3.94 in)
- Height: 55 mm (2.16 in)



## Battery

Type	2-cell prismatic (32 WHr)
Operating time	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.
Life span (approximate)	300 discharge/charge cycles
Temperature range: Operating	0°C to 35°C (32°F to 95°F)
Temperature range: Storage	-40°C to 65°C (-40°F to 149°F)
Coin-cell battery	CR-2032
Weight (maximum)	0.19 kg (0.42 lb)
Voltage	7.6 VDC
Charging time when the computer is off (approximate)	Within 4 hours
Width	272.10 mm (10.71 in)
Depth	70.50 mm (2.78 in)
Height	6.82 mm (0.27 in)

## Power Adapter

Type	45 W	65 W
Input voltage	100 VAC–240 VAC	
Input frequency	50 Hz–60 Hz	
Input current (maximum)	1.30 A	1.70 A
Output current (continuous)	2.31 A	3.34 A
Rated output voltage	19.50 VDC	
Temperature range: Operating	0°C to 40°C (32°F to 104°F)	
Temperature range: Storage	-40°C to 70°C (-40°F to 158°F)	

# Computer Environment

**Airborne contaminant level:** G1 as defined by ISA-S71.04-1985

	<b>Operating</b>	<b>Storage</b>
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G <sup>†</sup>	160 G <sup>‡</sup>
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)
















\* Measured using a random vibration spectrum that simulates user environment.

† Measured using a 2 ms half-sine pulse when the hard drive is in use.

‡ Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

# Keyboard shortcuts

---

Icons	Description
	Mute audio
	Decrease volume
	Increase volume
	Play previous track/ chapter
	Play/Pause
	Play next track/chapter
	Switch to external display
	Search
	Decrease brightness
	Increase brightness
	Pause/Break
	Toggle Fn-key lock
	Sleep
	Turn off/on wireless
	Scroll lock

# Getting help and contacting Dell

---

## Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Information about Dell products and services [www.dell.com](http://www.dell.com)

Windows 8.1 and Windows 10

Dell Help & Support app



Windows 10

Get started app



Windows 8.1

Help + Tips app



Accessing help in Windows 8, Windows 8.1, and Windows 10

In Windows search, type **Help and Support**, and press **Enter**.

Accessing help in Windows 7

Click **Start** → **Help and Support**.

Online help for operating system

[www.dell.com/support/windows](http://www.dell.com/support/windows)

[www.dell.com/support/linux](http://www.dell.com/support/linux)

[www.dell.com/support](http://www.dell.com/support)

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on

Learn about your operating system, setting up and using your computer, data backup, diagnostics, and so on.

See *Me and My Dell* at

[www.dell.com/support/manuals](http://www.dell.com/support/manuals).

# Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see [www.dell.com/contactdell](http://www.dell.com/contactdell).



**NOTE:** Availability varies by country and product, and some services may not be available in your country.



**NOTE:** If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.